



Extend just the Counter to mate with the Base Cabinet Build-out.  
Leave the Uppers on-plane with a surface-mounting of the Wall Surface.

Build-out the Base Cabinets an extra 2",  
but leave the Fillers on-plane with the Fillers above.